

Please check that you have all the required components on site to complete the installation

HENLEY 2 WAY

2.4m Gate Posts	X 2	<input checked="" type="checkbox"/>
Gate - 1.6m	X 1	<input checked="" type="checkbox"/>
Easy Latch kit 2 WAY	X 1	<input checked="" type="checkbox"/>
180 degree selfclosing hinge	X 1	<input checked="" type="checkbox"/>

ASTON 2 WAY

2.4m Gate Posts	X 2	<input checked="" type="checkbox"/>
Gate - 1.2m	X 1	<input checked="" type="checkbox"/>
Easy Latch kit 2 WAY	X 1	<input checked="" type="checkbox"/>
180 degree selfclosing hinge	X 1	<input checked="" type="checkbox"/>



Additional Options - Gate End Striker (instead of easy latch)
 - trombone handle is supplied as standard, this can be replaced with straight or stockproof handle (additional charge for the stockproof handle)

Installed Height - 1.2m
 Width post to post - ASTON - 1.7m
 - HENLEY - 2.1m

Both Gates are designed to Hang between the gate posts.



If you need any further advice/guidance regarding the installations of any of these products please contact the office on the number below.

Installation Instructions

1 PREPARE THE GATE

- Attach the 24" hinge to the gate as follows. - Mark the position of the three holes on each side.
- Drill approximately halfway through the top rail from each side and hope to meet in the middle.
- Feed the coach bolts through and tighten up.
- Drill the hanging stile on the gate to take the bottom hinge which fits between the bottom 2 rails
- Fit the EASY LATCH kit (see illustration) or the gate end striker

2 PREPARE THE GATEPOST

- Decide where the gate should hang on the post and mark the position of the bolt and bottom hinge.
- Drill the gatepost for the top bolt. A short hole is also needed for the locking bar.
- Attach the bottom hinge.

3 INSTALL THE GATEPOSTS AND GATES

- Dig the hole for the hanging post, insert it and ram the bottom of hole with stones or rubble. Check that the post remains upright.
- Backfill the hole with the most solid material available
- Attach the gate. The bottom hinge will need to be removed and then attached again when the gate is in position.
- Check that the gate is level and upright in the closed position and adjust the top bolt as necessary.
- Install the slam post so that the gap between the gate and the post is 50mm. This can easily be achieved by attaching a 50mm batten to the end of the gate and then installing the post.
- Attach the TWO WAY CATCH and GUIDE(see illustration)
- Cut off the excess length on the EASY LATCH
- Fit the STOCKPROOF HANDLE(see illustration) and attach the label with the Arrows(optional)

4 COMPLETION

- Re-check that the gate and posts are upright and level and tighten all nuts
- Cut away any excess thread
- Check that the gate is completely free of all sharp edges
- Check that the gate closes freely from both directions. If the gate sticks, file off any excess galvanising or pinch points until it swings free
- Coach screws can be inserted into the hanging post to strike the top hinge on both sides to act as a gate stop if required